


Instruction Manual

Model 1586-04-0431 RF Attenuator

April 2021, Rev 0



Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588


WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

INSTRUCTION MANUAL
MODEL 1586-06 RF Attenuator

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
Warranty	2
1.0 General	3
1.1 Equipment Description	3
1.2 Technical Characteristics	4
1.3 Monitor & Control Interface	5
2.0 Installation	10
2.1 Mechanical	10
2.2 Rear I/O's	11
2.3 Front Panel Controls, Indicators	11
2.4 Operation	12
2.5 Menu Settings	13
2.6 Environmental Use Information	17

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are no other warranties, express or implied, except as stated herein.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

MODEL 1586-04-0431 RF Attenuator

1.0 General

1.1 Equipment Description - The 1586-04-0431 Programmable Attenuator contains two 0.5 to 4 GHz and two 25 to 31 GHz Digital PIN Attenuators and Local/Remote control circuitry to independently adjust each attenuator. Multi-function push button switches select the attenuation locally. The attenuator values are stored in nonvolatile memory so these values remain when power is cycled off and on. Front panel LEDs provide indication of DC power (green), Alarm (red), and Remote (yellow). Each Attenuator provides an attenuation range of 60 dB from **10 to 70 dB** attenuation. Remote operation also controls each attenuator, provides status monitoring of attenuator settings, power supply, and summary alarms. Attenuator settings appear on the LCD display. An **“Offset”** command allows adding an external attenuator to shift the attenuation range by the amount of the attenuator with the total attenuation shown on the display and via the M&C. Connectors are SMA, female (CH1, CH2) or 2.92 mm (CH3, CH4) for inputs and outputs and DB9 female for the RS422 remote control (**Ethernet Optional**). It is powered by a 100-240 $\pm 10\%$ VAC power supply (**Option -R for redundant supplies**), and in a 1 3/4” X 19” X 16” rack mount chassis.




FIGURE 1.1 Model 1586-04-0431 RF Attenuator Front and Rear Panels




FIGURE 1.2 Model 1586-04-0431 RF Attenuator Block Diagrams

1.2 Technical Characteristics

TABLE 1.1 Model 1586-04-0431 RF Attenuator Technical Characteristics

EQUIPMENT SPECIFICATIONS*		
Input Characteristics	CH 1,2	CH 3,4
Impedance/Return Loss	50Ω/14 dB	50Ω/14 dB
Frequency	0.5-4.0 GHz	25.0-31.0 GHz
Input No Damage	+20 dBm	+20 dBm
Input Level range	0 to -20 dBm	0 to -20 dBm
Input 1 dB comp, min att	+10 dBm	+10 dBm
Output Characteristics		
Impedance/Return Loss	50 Ω /14 dB	50 Ω /14 dB
Frequency (GHz)	0.5-4.0 GHz	25.0-31.0 GHz
Output Level Range	-20 to -80 dBm	-20 to -80 dBm
Channel Characteristics		
Attenuation, min. at Fc	10 ±1 dB	10 ±1 dB
Att. range, 0.5±0.5 dB steps	10 to 70 dB	10 to 70 dB
Freq. Resp. @att range		
10 to 30 dB	±1.5 dB	±1.5 dB
31 to 50 dB	±2.0 dB	±2.0 dB
51 to 70 dB	±2.5 dB	±2.5 dB
Att Accuracy @att range, Fc		
10 to 30 dB	±1.0 dB	±1.0 dB
31 to 50 dB	±1.0 dB	±1.0 dB
51 to 70 dB	±1.5 dB	±1.5 dB

Other

Temp Coefficient ±0.025 dB/Degree C, max.

Controls, Indicators

Gain Direct readout LCD; pushbutton switches or remote
Offset Shifts attenuation range by the amount of ext attenuator
 Power; Alarm; Remote Green LED; Red LED; Yellow LED
 Remote RS232C/RS485/422, 9600 baud (Ethernet Optional)

Other


CH 1,2; CH 3,4 Con. SMA (female); 2.92 mm (female), 50Ω
 Alarm Connector DB9 - NO or NC contact closure on Alarm
 Size 19 inch standard chassis 1.75" high X **19"** deep
 Power 100-240 ± 10% VAC, 47 - 63 Hz, **25** watts maximum

*+10 to +40 degrees C; Specifications subject to change without notice

1.3 Monitor and Control Interface

A) Remote serial interface

Protocol: RS-232C, 9600 baud rate, no parity, 8 data bits, 1 start bit, and 1 stop bit.
(RS-232C, RS-422, or RS-485)



Connector: Rear panel, DB-9 male

J10 Pinouts (RS-232C/422/485)	
Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

B) Status Requests -

Table 1.1 lists the M&C commands for the 1586-04-0431 and briefly describes them.

* PLEASE NOTE: The two character {aa}(00-31) prefix, in the table below, should be used ONLY when RS-485 is selected.

TABLE 1.1 1586-04-0431 Commands		
Command	Syntax *	Description
Set Channel 1 Gain	{aaCAyyyy}	where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		A = command code (case sensitive, capital A)
		yyyy = Channel gain in dB.
		Range: channel 1 offset -10.0 to channel 1 offset -70.0 in 0.5 dB steps; the decimal point is optional.
		example: {CA-455}
		Will set channel 1 total gain (including offset) to -45.5 dB. The unit will reply with the '>' character if the command is successfully processed.
Set Channel 1 Offset	{aaCayy}	where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		a = command code (case sensitive, lower case a)
		yy = Channel offset in dB. This value reflects any external attenuation added to the system.
		Range: 00 to 60 dB.
		example: {Ca40}
		Will set channel 1 external attenuation offset to 40 dB. The unit will reply with the '>' character if the command is successfully processed.
Set Channel 2 Gain	{aaCByyyy}	where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		B = command code (case sensitive, capital B)
		yyyy = Channel gain in dB.
		Range: channel 2 offset -10.0 to channel 2 offset -70.0 in 0.5 dB steps; the decimal point is optional.
		example: {CB455}
		Will set channel 2 total gain (including offset) to -45.5 dB. The unit will reply with the '>' character if the command is successfully processed.
Set Channel 2 Offset	{aaCbyy}	where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		b = command code (case sensitive, lower case b)
		yy = Channel offset in dB. This value reflects any external attenuation added to the system.
		Range: 00 to 60 dB.
		example: {Cb40}
		Will set channel 2 external attenuation offset to 40 dB. The unit will reply with the '>' character if the command is successfully processed.

TABLE 1.1 Continued: 1586-04-0431 Commands

Command	Syntax *	Description
Set Channel 3 Gain	{aaCCyyyy}	where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		C = command code (case sensitive, capital C)
		yyyy = Channel gain in dB.
		Range: channel 3 offset -10.0 to channel 3 offset -70.0 in 0.5 dB steps; the decimal point is optional.
		example: {CC-455}
		Will set channel 1 total gain (including offset) to -45.5 dB.
		The unit will reply with the '>' character if the command is successfully processed.
Set Channel 3 Offset	{aaCcyy}	where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		c = command code (case sensitive, lower case c)
		yy = Channel offset in dB. This value reflects any external attenuation added to the system.
		Range: 00 to 60 dB.
		example: {Cc40}
		Will set channel 3 external attenuation offset to 40 dB.
		The unit will reply with the '>' character if the command is successfully processed.
Set Channel 4 Gain	{aaCDyyyy}	where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		D = command code (case sensitive, capital D)
		yyyy = Channel gain in dB.
		Range: channel 4 offset -10.0 to channel 4 offset -70.0 in 0.5 dB steps; the decimal point is optional.
		example: {CD455}
		Will set channel 4 total gain (including offset) to -45.5 dB.
		The unit will reply with the '>' character if the command is successfully processed.
Set Channel 4 Offset	{aaCdy}	where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		d = command code (case sensitive, lower case d)
		yy = Channel offset in dB. This value reflects any external attenuation added to the system.
		Range: 00 to 60 dB.

B) Status Requests -

Table 1.2 lists the status requests for the 1586-04-0431 and briefly describes them.

* PLEASE NOTE: The two character {aa}(00-31) prefix, in the table below, should be used ONLY when RS-485, (OPTION-Q), is selected.


TABLE 1.2 1586-0400431 Status Requests		
Command	Syntax *	Description
Get Channel 1 Gain	{aaSA}	returns {aaSAyyy.y}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		A = command code (case sensitive, capital A)
		yyy.y = Channel gain in dB.
		The unit will reply with the '>' character if the command is successfully processed.
Get Channel 1 Offset	{aaSa}	returns {aaSaiyy}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		a = command code (case sensitive, lower case a)
		yy = Channel offset in dB.
		The unit will reply with the '>' character if the command is successfully processed.
Get Channel 2 Gain	{aaSB}	returns {aaSByyy.y}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		B = command code (case sensitive, capital B)
		yyy.y = Channel gain in dB.
		The unit will reply with the '>' character if the command is successfully processed.
Get Channel 2 Offset	{aaSb}	returns {aaSbiiy}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		b = command code (case sensitive, lower case b)
		yy = Channel offset in dB.
		The unit will reply with the '>' character if the command is successfully processed.
Get Channel 3 Gain	{aaSC}	returns {aaSCyyy.y}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		C = command code (case sensitive, capital C)
		yyy.y = Channel gain in dB.
		The unit will reply with the '>' character if the command is successfully processed.

TABLE 1.2 Continued: 1586-0400431 Status Requests

Command	Syntax *	Description
Get Channel 3 Offset	{aaSc}	returns {aaScyy}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		c = command code (case sensitive, lower case c)
		yy = Channel offset in dB.
		The unit will reply with the '>' character if the command is successfully processed.
Get Channel 4 Gain	{aaSD}	returns {aaSDyyy.y}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		D = command code (case sensitive, capital D)
		yyy.y = Channel gain in dB.
		The unit will reply with the '>' character if the command is successfully processed.
Get Channel 4 Offset	{aaSd}	returns {aaSdyy}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		d = command code (case sensitive, lower case d)
		yy = Channel offset in dB.
		The unit will reply with the '>' character if the command is successfully processed.
Get Unit Alarm Status	{aaSL}	returns {aaSLx}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		L = command code
		x = 0 for alarm off, 1 for alarm on.
		The unit will append the '>' character if the command is successfully processed.
Get Product Info	{aaSV}	returns {aaSV1586-04-0431rev.5xx}
		where:
		aa = unit address, range = 00 to 31, only used if interface is RS485, otherwise omit
		V = command code
		The unit will append the '>' character if the command is successfully processed.
		returns {aaSixxx.xxx.xxx.xxx}

2.0 Installation

2.1 Mechanical - The 1586-04-0431 consists of one Controller PCB assembly, two General Microwave Model 346C 10 Bit Digital PIN Attenuators and two General Microwave Model 3499 11 Bit Digital PIN attenuators housed in a 1 RU (1 3/4 inch high by 19 inch deep) chassis. One 100-240 VAC, 25W power supply provides redundant power for the assemblies. The 1586-04-0431 can be secured to a rack using the 4 holes on the front panel. Figure 2.0 shows how the 1586-04-0431 is assembled.



Model 1586 -04-0431 RF Attenuator Assembly Layout

FIGURE 2.0 1586-04-0431 Mechanical Assembly

2.2 Rear Panel Input/Output Signals - Figure 2.1 shows the input and output connectors on the rear panel.




FIGURE 2.1 1586-04-0431 Rear Panel I/O's

2.3 Front Panel Controls and Indicators -The following are the front panel controls and indicators.




FIGURE 2.2 1586-04-0431 Front Panel Controls and Indicators

2.4 Installation / Operation

2.4.1 Installing and Operating the 1586-04-0431 RF Attenuator

- 1.) Connect 0 to -20 dBm signal(s) to any or all of the four RF Attenuator Inputs (Figure 2.1).
- 2.) Connect the desired RF Attenuator Outputs to the external equipment (Figure 2.1).
- 3.) Connect 100-240 \pm 10% VAC, 47 - 63 Hz to AC1 and/or AC2 on the back panel.
- 4.) Set the desired gain and attenuation offset for each attenuator (See Section 2.5 Menu Settings).
- 5.) Be sure DS1 (DC Power) is green (Figure 2.2).
- 6.) **AC Fuses** - The fuses are 5 mm X 20 mm, 2 amp slow blow (Type T) and are inserted in the far slot in the drawer below the AC inputs as shown in Figure 2.3. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.




FIGURE 2.3 Fuse Location and Spare Fuse

2.5 Menu Settings

2.5.1 Functions

This section describes operation of the front panel controls. There are three operator switches, the LCD display and alarm indicator LEDs. All functions for the equipment are controlled by these components. The functions are (see Figure 2.5):

Power Up

Normal Display

Menu 1	CH 1 GAIN, OFFSET
Menu 2	CH 2 GAIN, OFFSET
Menu 3	CH 3 GAIN, OFFSET
Menu 4	CH 4 GAIN, OFFSET
Menu 5	Set REMOTE
Menu 6	Set Interface
Menu 7	Set RS485 address
Menu 8	Reset Ethernet Settings

Save Menu When “R” is selected in any above menu or the next menu item after Menu 8

Alarm indications appear on the LEDs (see figure 2.2).

All program changes must start with the operation of the Menu/Execute switch and must also end with the operation of the Menu/Execute switch verified by the “Save Settings?” Menu. If this sequence is not followed, none of the changes will take effect. If programming is initiated and no operator action takes place for approximately 12 seconds (before the final press of the Menu/Execute switch) the display will revert to its previous status and you will need to start over.

2.5.2. Power On Settings

NOTE: The last status of a unit is retained even when power is removed. When power is restored, the unit will return to its previous settings.

When power is first applied, the LCD display goes through three steps.

1. The LCD goes black to show all segments are functioning.
2. The software version will be displayed.

REV 5.20

3. The present gain of each attenuator is shown.

G1=-33.0	G2=-41.0
G3=-17.0	G4=-52.0

The unit is now operational and ready for any changes the operator may desire.

2.5.3 Control Switches

1. Menu/Execute - Any change to the programming of the unit must be initiated by pressing the Menu/Execute switch and completed by pressing the Menu/Execute switch.
2. Horizontal Switch - This switch is mounted so its movement is horizontal and moves the cursor left or right.
3. Vertical Switch - This switch is mounted so its movement is vertical and has two functions:
 - A. During frequency, gain changes, the vertical movement will raise or lower the selected number in the direction of the arrows.
 - B. For other functions, the vertical switch will alternately turn the function on or off regardless of the direction operated.

2.5.4 Gain and Offset Changes

The nominal gain through each channel is adjustable from -10.0 dB to -70.0 dB. Each channel has an offset value that allows you to add external attenuation that will automatically be reflected in the gain value displayed for that channel. The offset value is adjustable from 0 to 60 in 1 dB steps.

The gain and offset changes will be made as you make them but if you do not wish to save the changes you have made, scroll to “R” and push the menu/Execute switch and select “NO” in the “SAVE SETTINGS?” window or **do not press the Menu/Execute switch**; simply do nothing for approximately 30 seconds, and the system will return to the normal operating mode.

To change the GAIN or OFFSET, first push the Menu/Execute switch to get to the desired channel’s gain/offset menu setting:

Operate the Menu/Execute switch until you get to the menu item you want to change (see Figure 2.5 for the sequence of menu options). The following display is for changing the gain and offset for channel 1:

```
CH1 GAIN=-33.0
CH1 OFFSET=+20 R
```

NOTE: CHANGES TAKE PLACE ON GAIN AND OFFSET IMMEDIATELY BUT DO NOT GET SAVED UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES.

Press the Up/Down switch to change the gain in 0.5 dB steps. Use the left/right switch to navigate from gain to offset. Press the Up/Down switch to adjust the external attenuation offset value. The gain value will be adjusted to reflect the new offset value at the time that the changes are made.

NOTE: THE GAIN AND OFFSET WILL BE CHANGED AS YOU ADJUST THE NUMBERS. HOWEVER, THE VALUE WILL NOT BE STORED UNTIL YOU INDICATE YES IN THE SAVE SETTINGS WINDOW.

When the display indicates the value desired you can push the Menu/Execute switch to the next item OR you can scroll to “R”, push the Menu/Execute switch to get to:

```
SAVE SETTINGS? Y N
```

Selecting Y will save the new settings. Selecting N will revert to the previous settings.

Pushing the Menu/Execute switch then takes you to:

```
G1=-33.0 G2=-41.0
G3=-17.0 G4=-52.0
```

Figure 2.5 gives the menu items and how to make changes

2.5.5 Alarm Indications

An alarm condition will occur if the +12 VDC or -12VDC power supplies (to the internal attenuators) are out of range.

	ON POWER UP		
Power Up	1586-04-0431W8W28 5.20		
<hr style="border: 1px solid black;"/>			
	NORMAL DISPLAY		
Normal Display	G1=-33.0 G2=-41.0 G3=-17.0 G4=-52.0		PUSH BUTTON
<hr style="border: 1px solid black;"/>			
	PUSHING MENU/EXECUTE SEQUENCE		
Menu 1 CH 1 GAIN, OFFSET	CH1 GAIN=-33.0 CH1 OFFSET=+20 R	SCROLL <> SCROLL ⤵	PUSH BUTTON
Menu 2 CH 2 GAIN, OFFSET	CH2 GAIN=-41.0 CH2 OFFSET=+10 R	SCROLL <> SCROLL ⤵	PUSH BUTTON
Menu 3 CH 3 GAIN, OFFSET	CH3 GAIN=-17.0 CH3 OFFSET=+00 R	SCROLL <> SCROLL ⤵	PUSH BUTTON
Menu 4 CH 4 GAIN, OFFSET	CH4 GAIN=-52.0 CH4 OFFSET=+30 R	SCROLL <> SCROLL ⤵	PUSH BUTTON
Menu 5 Set REMOTE	REMOTE ON R	SCROLL <> SCROLL ⤵	PUSH BUTTON
Menu 6 Set Interface	INTERFACE R RS232	SCROLL <> SCROLL ⤵	PUSH BUTTON
Menu 7 Set RS485 address	RS485 ADDR 01 R	SCROLL <> SCROLL ⤵	PUSH BUTTON
Menu 8 Reset Ethernet Settings	RESET ETHERNET R SETTINGS NO	SCROLL <> SCROLL ⤵	PUSH BUTTON
Menu 9 Save Settings When "R" is selected from any menu above, or at the end	SAVE SETTINGS? YN	SCROLL <>	PUSH BUTTON

FIGURE 2.5 Menu Display and Sequence

1.4 Environmental Use Information

- A. Rack-Mounting** - To mount this equipment in a rack, please refer to the installation instructions located in the user manual furnished by the manufacturer of your equipment rack.
- B. Mechanical Loading** - Mounting of equipment in a rack should be such that a hazardous condition does not exist due to uneven weight distribution.
- C. Elevated Operating Ambient Temperature** - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack may be greater than room ambient temperature. Therefore, consideration should be given to T_{mra} .
- D. Reduced Air Flow** - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. Additional space between units may be required.
- E. Circuit Overloading** - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of circuits could have on over current protection and supply wiring. Appropriate consideration of equipment name plate rating should be used, when addressing this concern.
- F. Reliable Earthing** - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connection to the Branch (use of power strips).
- G. Top Cover** - There are no serviceable parts inside the product so, the Top Cover should not be removed. If the Top Cover is removed the ground strap and associated screw **MUST BE REINSTALLED** prior to Top Cover screw replacement. **FAILURE TO DO** this may cause **INGRESS** and/or **EGRESS** emission problems.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

Printed in USA • 2021