

Instruction Manual

Model 2116-84T78 Block Translator

December 2019, Rev. 0



Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

INSTRUCTION MANUAL

MODEL 2116-84T78 Block Translator

| <u>TABLE OF CONTENTS</u> | <u>PAGE</u> |
|--|-------------|
| Warranty | 2 |
| 1.0 General | 3 |
| 1.1 Equipment Description | 3 |
| 1.2 Technical Characteristics | 4 |
| 2.0 Installation | 5 |
| 2.1 Mechanical | 5 |
| 2.2 Rear Inputs and Outputs | 6 |
| 2.3 Front Panel Indicators | 6 |
| 2.4 Operation | 7 |
| 3.0 Environmental Use Information | 8 |

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

MODEL 2116-84T78 Block Translator

1.0 General

1.1 Equipment Description

The 2116-84T78 Block Translator converts 7.90 - 8.40 GHz to 7.25 - 7.75 GHz with a local oscillator at 0.65 GHz. Front panel LEDs provide indication of DC Power, External 10 MHz, and PLL Alarm. The gain is -30 dB. Connectors are SMA female for RF In and RF Out and BNC female for the external reference input and reference output. A three-way switch controls which 10 MHz reference is being used. When in the AUTO position, the internal reference is used unless a +3 dBm \pm 3 dB, 10MHz reference signal is connected to the external reference input. The 2116 is powered by a 100-240 \pm 10% VAC power supply, and mounted in a 1 3/4" X 19" X 14" rack mount chassis.




FIGURE 1.1 Front and Rear Panels




FIGURE 1.2 Block Diagram

1.2 Technical Characteristics

TABLE 1.0 2116-84T78 Block Translator Specifications*

Input Characteristics

| | |
|-----------------------|---|
| Impedance/Return Loss | 50 Ω /14 dB min. (see TABLE 2.2 for connector options) |
| Frequency | 7.90 to 8.40 GHz |
| Input Level Range | -30 to -10 dBm |
| Input 1dB Compression | 0 dBm |

Output Characteristics

| | |
|------------------------|--|
| Impedance/Return Loss | 50 Ω /14 dB (see TABLE 2.2 for connector options) |
| Frequency | 7.25 to 7.75 GHz |
| Output Level Range | -60 to -40 dBm |
| Output 1dB compression | -30 dBm |

Channel Characteristics

| | |
|-----------------------------|--|
| Gain | -30 dB \pm 2 dB at Fc |
| Input/Output Isolation | >40 dB minimum |
| Intermodulation | >50 dBC for two carriers each at -15 dBm in |
| Spurious, Inband | SIGNAL RELATED<-50 dBC,typical -40 dBC max; SIGNAL INDEPENDENT<-80 dBm; |
| Spurious, Out of band, LO | <-45 dBm, at 7.15 and 7.80 GHz at the output |
| Spurious, Out of band, sig. | <-20 dBc, Fc \pm 1 GHz, <-40 dBc, Fc \pm 2 GHz at the output |
| Frequency Response | \pm 2.0 dB, over frequency band; \pm 0.5 dB, 40 MHz BW |
| Frequency Sense | Non-inverting |

LO Characteristics

| | |
|---------------------|---|
| LO Frequency | 0.65 GHz |
| Frequency Accuracy | \pm 0.01 ppm max. over temp internal reference; ext. ref. input |
| 10 MHz In/Out Level | +3 dBm \pm 3 dB |

| Phase Noise @ Freq | 10Hz | 1kHz | 10kHz | 100kHz | 1MHz |
|--------------------|------|------|-------|--------|------|
| dBC/Hz | -70 | -80 | -85 | -95 | -110 |

Controls, Indicators

| | |
|------------------|--|
| Power | Green LED |
| PLL Alarm | Red LED, External contact closure |
| Ext 10 MHz | Yellow LED, indicates ext. 10 MHz ref. selected (rear panel DPDT switch) |
| 10 MHz Reference | 3-way Switch (selects INTERNAL, EXTERNAL, or AUTO mode) |

Other

| | |
|-------------------------|---|
| RF In/RF Out Connectors | SMA (female) 50 Ω |
| 10 MHz Connectors | BNC (female), 50 Ω /75 Ω |
| Alarm Connector | DB9 (female) - NO or NC contact closure on alarm |
| Size | 19 inch, 1RU standard chassis 1.75" High X 14.0" Deep |
| Power | 100-240 \pm 10 VAC, 47-63 Hz, 45 watts max. |

Options

| | |
|-------------------|---------------|
| Connector Options | See TABLE 2.2 |
|-------------------|---------------|

*0°C to +40°C; Specifications subject to change without notice.

2.0 Installation

2.1 Mechanical

The 2116-84T78 consists of one RF PCB housed in a 1 RU (1 3/4 inch high) by 14 inch deep chassis. A switching, ± 12 , +24, +5 VDC power supply provides power for the assemblies. The 2116-84T78 can be secured to a rack using the 4 holes on the front panel. Figure 2.0 shows how the 2116-84T78 is assembled.




FIGURE 2.0 2116-84T78 Mechanical Assembly

2.2 Rear Panel Input/Output Signals

Figure 2.1 shows the input and output connectors on the rear panel.




FIGURE 2.1 2116-84T78 Rear Panel I/O's

| Pin | Function |
|-----|------------------------------|
| 1 | Not Used |
| 2 | Not Used |
| 3 | Not Used |
| 4 | Not Used |
| 5 | GND |
| 6 | Alarm Relay: Common |
| 7 | Alarm Relay: Normally Open |
| 8 | Not Used |
| 9 | Alarm Relay: Normally Closed |

| Option | RF Input | RF Output |
|--------|-------------|-------------|
| STD | SMA, 50Ω | SMA, 50Ω |
| NN | N-Type, 50Ω | N-Type, 50Ω |

2.3 Front Panel Indicators

Figure 2.2 shows the front panel indicators.




FIGURE 2.2 2116-84T78 Front Panel Controls and Indicators

2.4 Installation / Operation

2.4.1 Installing and Operating the 2116-84T78 Block Translator

1. Connect a -30 to -10 dBm (7.90 to 8.40 GHz) signal to 0 RF INPUT (J101) (Figure 2.1).
2. Connect RF OUT (J102) to the external equipment. (7.25 to 7.75).
3. Connect a 100-240 \pm 10% VAC, 47 - 63 Hz to AC connector on the back panel.
4. Be sure DS1 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.2).
5. Select either INT. (for internal 10MHz ref), AUTO (for internal 10MHz ref UNLESS an external 10MHz, 3 dBm signal is connected to J2), or EXT (for external 10MHz, 3 dBm ref that is inserted at J2) using the rear panel 3-way switch, S1 (Figure 2.1).
6. If EXT is selected or AUTO is selected and there is a 10MHz, 3 dBm signal at J2, check that DS3 (yellow, Ext 10MHZ) is on (Figure 2.2).
7. Check that a 10MHz, 3 dBm \pm 3 dB signal is present at the 10MHZ REF OUTPUT (J8) (Figure 2.1).
8. AC Fuse - The fuse is a 5 mm X 20 mm, 2 amp slow blow (Type T) and is inserted in the far slot in the drawer below the AC input as shown in Figure 2.3. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.




FIGURE 2.3 Fuse Location and Spare Fuse

3.0 Environmental Use Information

- A. **Rack-Mounting** - To mount this equipment in a rack, please refer to the installation instructions located in the user manual furnished by the manufacturer of your equipment rack.
- B. **Mechanical loading** - Mounting of equipment in a rack should be such that a hazardous condition does not exist due to uneven weight distribution.
- C. **Elevated operating ambient temperature** - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack may be greater than room ambient temperature. Therefore, consideration should be given to Tmra.
- D. **Reduced air flow** - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. Additional space between units may be required.
- E. **Circuit Overloading** - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of circuits could have on over current protection and supply wiring. Appropriate consideration of equipment name plate rating should be used, when addressing this concern.
- F. **Reliable Earthing** - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connection to the Branch (use of power strips).
- G. **Top Cover** - There are no serviceable parts inside the product so, the Top Cover should not be removed. If the Top Cover is removed the ground strap and associated screw **MUST BE REINSTALLED** prior to Top Cover screw replacement. **FAILURE TO DO** this may cause **INGRESS** and/or **EGRESS** emission problems.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

PRINTED IN USA