


Instruction Manual

Model 3116-T12-1311 Translator

August 2022, Rev. 0



Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB www.crosstechnologies.com
E-MAIL info@crosstechnologies.com

INSTRUCTION MANUAL

3116-T12-1311 Multi-Band Block Downconverter, Loop Back Only

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
Warranty	2
1.0 General	3
1.1 Equipment Description	3
1.2 Technical Characteristics	4
1.3 Monitor & Control Interface	6
2.0 Installation	8
2.1 Mechanical	8
2.2 Rear Panel Inputs & Outputs	9
2.3 Front Panel Controls & Indicators	10
2.4 Installation/Operation	11
2.5 Menu Settings	12
3.0 Environmental Use Information	15

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



6170 Shiloh Road

Alpharetta, Georgia 30005

(770) 886-8005 FAX (770) 886-7964

Toll Free (888) 900-5588

WEB www.crosstechnologies.com

E-MAIL info@crosstechnologies.com

MODEL 3116-T12-1311 Translator, Loop Back Only

1.0 General

1.1 Equipment Specifications

3116-T12-1311 Translator 12.75-13.25 GHz to 10.7-11.2 or 11.2-11.7 GHz

The 3116-T12-1311 Translator converts 12.75-13.25 GHz to 10.7-11.2 or 11.2-11.7 GHz with a 2.05 or 1.55 GHz local oscillator. Front panel LEDs provide indication of Remote operation, PLL Alarm, and DC Power. The RF to RF gain is +25 dB, maximum. Connectors are SMA female for RF out, RF in, and OPTIONAL RF Monitors (RF in, Opt W86; RF out, Opt W85) and BNC female for external 10 MHz in and 10 MHz out. In AUTO, the 10 MHz reference stays in external if the external level is +3 dBm, ±3 dB. Gain, LO frequency and internal 10 MHz frequency are controlled by the front panel switches or the M&C connector (Ethernet optional). It is powered by a 100-240 ±10% VAC power supply and is in a 1.75" X 19" X 14" rack mount chassis.




Figure 1. Model 3116-T12-1311 Translator, Front & Rear Panels




Figure 1-A Model 3116-T12-1311 Translator Block Diagram

TABLE 1.0 3116-T12-1311 Translator Specifications**

Input Characteristics	
Impedance/Return Loss	50Ω/12 dB, 14 dB typical
Frequency (GHz)	12.75 - 13.25 GHz
Noise Figure, Maximum	25 dB at max gain
Input Level Range	-30 to -10 dBm
Output Characteristics	
Impedance/Return Loss	50Ω / 12 dB, 14 dB typical
Frequency (GHz)	10.7-11.2 or 11.2-11.7 GHz
Output Level Range	-30 to 0 dBm
Output 1 dB compression	+8 dBm, +10 typical
Channel Characteristics	
Gain, Maximum	+25 ±3 dB a Fc
Gain Range	+25 to 0 dB; 0.5±0.5 dB steps
In to Out Isolation, Minimum	>40 dBc, >50 typical
Spurious, Inband	> 40 dBc
Spurious, Out of Band	<-20 dBc, Fc ±1 GHz, <-40 dBc, Fc±2 GHz
2 tone @ -10 dBm out each	>45 dBc, 50 typical, Gain = +25 (carriers at Fc ± 2 MHz)
Frequency Response, Band	± 2 dB (10.7-11.2 or 11.2-12.7 GHz)
Frequency Response, 40 MHz	± 0.5 dB
Frequency Sense	Non-Inverting
LO Characteristics	
LO Frequency	2.05 or 1.55 GHz
Frequency Accuracy	± 0.01 ppm maximum over temp internal reference; external reference input
10 MHz In/Out Level	+3 dBm, ±3 dB

Phase Noise @ Frequency	100	1k	10k	100k	1M
dBC/Hz	-70	-80	90k	-100	-110

Controls, Indicators	
Gain, 10M Frequency	Gain & internal 10 MHz frequency, Front Panel Switches or M&C connector (Ethernet Optional).
PLL Alarm	Red LED; External Contact Closure
Power	Green LED
Remote	RS232C, RS485; 9600 baud (Ethernet Optional)
Other	
RF In/RF Out Monitor Connector	SMA (female), 50Ω (RF In & RF Out monitors optional)
10 MHz Connectors	BNC (female), 75Ω; Works with 50Ω
Monitor/Control Connector	RS232C, DB9, Female; Optional Ethernet, RJ45, Female
Size	19 inch, 1RU Standard Chassis 1.75" high x 14.0" deep
Power	100-240 ±10% VAC, 47- 63 Hz, 30 watts maximum

**+10°C to +40°C Operating; -30°C to +60°C Non-Operating; 95% relative humidity, non-condensing; Specifications subject to change without notice.
© Cross Technologies, Inc. 2017

Available Options	
-W8	Ethernet; with Web Browser
-W18	Ethernet; with Web Browser & SNMP
-W28	Ethernet; with TCP/IP, Telnet
-W85	Out RF Monitor -20 dB
-W86	In RF Monitor +10 dB
Connectors/Impedance	
-NN	50Ω N-type (RF In,RF Out)
**+10°C to +40°C Operating; -30°C to +60°C Non-Operating; 95% relative humidity, non-condensing; Specifications subject to change without notice. © Cross Technologies, Inc. 2022	

1.3 Monitor & Control Interface

The following tables summarize the commands and status queries applicable to the 3116-T12-1311 Multi-Band Translator.

* **PLEASE NOTE:** The two character {aa} prefix, shown in the table below, is present ONLY when RS485 is selected.

Table 2.0 Model 3116-T12-1311 M&C Commands

Table 2.0: Model 3116-T12-1311 M&C Commands		
Command	Syntax	Description
Set Band	{aaCNx}	where:
		x = 1 to select band 1 (11.2 to 11.7 GHz out)
		x = 2 to select band 2 (10.7 to 11.2 GHz out)
Set Gain	{aaCGxxx}	where:
		xxx = 3 characters
		Range: 0 to 250 in 0.5 ±0.5 dB steps (e.g., 115=11.5 dB)
Set Mute	{aaCMx}	where:
		x = 1 to mute the output
		x = 0 to unmute the output
Set External Reference	{aaCEx}	where:
		x = 0 to select internal reference
		x = 1 to select external reference
		x = 2 for auto-select
Set Reference Offset	{aaCOxxxxx}	where:
		-2000 ≤ xxxxx ≤ +2000

continued on page 7...

Table 2.0 Model 3116-T12-1311 M&C Commands (continued)

Table 2.0: Model 3116-T12-1311 M&C Commands (continued)		
Command	Syntax	Description
Band	{aaSN}	Returns {aaSNx} where:
		x = 1 if band 1 is selected (11.2 to 11.7 GHz out)
		x = 2 if band 2 is selected (10.7 to 11.2 GHz out)
Gain	{aaSG}	Returns {aaSGxxx} where:
		xxx = 3 characters
		Range: (000 to +250 in 0.5 ±0.5 dB steps)
10 MHz reference	{aaSE}	Returns {aaSEx} where:
		x = 0 if Internal 10 MHz reference is selected
		x = 1 if External 10 MHz reference is selected
		x = 2 if in auto-select mode
Reference Status	{aaSB}	Returns {aaSBx} where:
		x = 0 if the internal reference is selected
		x = 1 if the external reference is selected
Unit Status	{aaSA}	Returns {aaSAx} where:
		x = 0 if no summary alarm, x = 1 if summary alarm
Reference Offset	{aaSO}	Returns {aaSOxxxxx} where:
		xxxxx is a signed number representing the ref. offset value
Model and firmware revision	{aaSV}	returns {aaSVxxxxxxxxxyyyy} where:
		xxxxxxxx = unit model number yyyy = unit firmware rev.

2.0 Installation

2.1 Mechanical - The 3116-T12-1311 Multi-Band Block Translator consists of a controller board and RF plate assembly. A switching ± 12 , $+24$, $+5$ VDC power supply provides power for the assemblies. The 3116-T12-1311 can be secured to a rack using the 4 holes on the front panel. Figure 2.0 shows how the 3116-T12-1311 is assembled.




FIGURE 2.0 3116-T12-1311 Mechanical Assembly

2.2 Rear Panel Input / Output Signals - Figure 2.2 shows the input and output connectors on the rear panel.




FIGURE 2.2 3116-T12-1311 Rear Panel Inputs and Outputs

TABLE 2.1 J10 Pinouts (RS-232C/422/485*)

Pin	Function
1	Rx-
2	Rx+ (RS-232C)
3	Tx+ (RS-232C)
4	Tx-
5	GND
6	Alarm Relay: Common
7	Alarm Relay: Normally Open
8	Not Used
9	Alarm Relay: Normally Closed

Available Options

W8 - Ethernet; w/Web Browser (WB)
W18 - Ethernet; w/WB & SNMP
W28 - Ethernet; w/TCP/IP, Telnet
W828 - Ethernet; W8 + W18 +W28
W85- Out RF Mon. -20 dB
W86- In RF Mon. +10 dB

Connectors/Impedance

NN- 50Ω N-type (RF In, RF Out)

TABLE 2.2 IF/RF Connector Options

Option	IF	RF
STD	BNC, 50Ω	Type N, 50Ω
-S	BNC, 50Ω	SMA, 50Ω
-N	BNC, 75Ω	Type N, 50Ω

*Interface: DB-9 Female

Protocol: RS485, RS422, or RS232C (selectable),

9600 baud rate, no parity, 8 data bits, 1 start bit, 1 stop bit

2.3 Front Panel Controls and Indicators -

Figure 2.3 shows the front panel controls and indicators.




FIGURE 2.3 3116-T12-1311 Front Panel Controls and Indicators

2.4 Installation/Operation

Installing and Operating the 3116-T12-1311 Translator:

1. Connect a -30 dBm to -10 dBm signal to RF INPUT (J101) Figure 2.2.
2. Connect the RF OUTPUT (J103), to the external equipment.
3. Connect 100-240 \pm 10% VAC, 47 - 63 Hz to AC connector to the front panel.
4. Be sure DS6 (green, DC Power) is on and DS2 (red, Alarm) is off (Figure 2.3).
5. Set the gain so that the output level is always within the range of 0 to -30 dBm (See Table 2.0).
6. Select either INT (for internal 10 MHz ref), or EXT (for external 10 MHz, +3 to +3 dBm reference that is inserted at J3).
7. AC Fuse - The fuse is a 1A/250V 1.25" x .25" (slow blow) and is inserted in the fuse F1 position.

NOTE: If a fuse continues to open, the power supply is most likely defective.




FIGURE 2.4 Fuse Location and Spare Fuse

2.5 Menu Settings

2.5.1 Functions - This section describes operation of the front panel controls. There are three operator switches, the LCD display and alarm indicator LEDs. All functions for the equipment are controlled by these components. The functions are (see Figure 2.3):

Power Up

Normal Display

Menu 1	Set Band
Menu 2	Gain in dB+25 to 0 dB; 0.5±0.5 dB Steps
Menu 3	Mute TX Signal
Menu 4	Select 10 MHz Reference (Internal, External, Auto)
Menu 5	Set Reference Frequency Offset
Menu 6	Set Remote on/off
Menu 7	Set Serial Interface
Menu 8	Set RS485 Address
Save Menu	When “R” is selected in any of the above menus or when operator reaches the end.

Alarm indications appear on the LEDs (See figure 2.3).

All program changes must start with the operation of the Menu/Execute switch and must also end with the operation of the Menu/Execute switch verified by the “Save Settings?” Menu. If this sequence is not followed, none of the changes will take effect. If programming is initiated and no operator action takes place for approximately 12 seconds, (before the final press of the Menu/Execute switch), the display will revert to its previous status and you will need to start over.

2.6 Power On Settings

NOTE: The last status of a unit is retained even when power is removed.

When power is restored, the unit will return to its previous settings.

When power is first applied, the LCD display goes through the following steps.

1. The LCD goes black to show all segments are functioning.
2. The model and software version will be displayed.
3. The IP address is read and displayed (if the unit has any ethernet option).
4. The present band, gain, 10 MHz reference and output frequency range are shown.

13.25>11.2	AUTO-E
G=+10	LO = 2.050

The unit is now operational and ready for any changes the operator may desire.

2.6.1 Control Switches

1. Menu/Execute - Any change to the programming of the unit must be initiated by pressing the Menu/Execute switch and completed by pressing the Menu/Execute switch.
2. Horizontal Switch - This switch is mounted so its movement is horizontal and moves the cursor left or right.
3. Vertical Switch - This switch is mounted so its movement is vertical and has two functions:
 - A. During frequency, gain changes, the vertical movement will raise or lower the number in the direction of the arrows.
 - B. For other functions such as Mute on/off, the vertical switch will alternately turn the function on or off regardless of the direction operated.

2.6.2 Gain Changes

When you get to this menu note that the gain changes will be made as you make them but if you do not wish to save the changes you have made, scroll to **“R”** and push the menu/Execute switch and select **“NO”** in the **“SAVE SETTINGS?”** window or **do not press the Menu/Execute switch**; simply do nothing for approximately 30 seconds and the system will return to the normal operating mode.

NOTE: CHANGES TAKE PLACE ON LEVEL AND GAIN IMMEDIATELY BUT DO NOT GET SAVED UNTIL YOU GO TO THE SAVE MENU AND INDICATE YOU WANT TO SAVE THE CHANGES.

Press the Up/Down switch to change the level in 0.5 dB steps and then push the Menu/Execute switch to get to the Gain setting:

GAIN = +11.5

Press the Up/Down switch to change the gain in 1 or 10 dB steps:

GAIN = +12.0

By using the horizontal rocker switch the cursor can be moved left or right. Pressing the Up/Down switch down will toggle the display digit selected until you have the desired gain.

When the display indicates the value desired you can push the Menu/Execute switch to the next item OR you can scroll to **“R”**, push the Menu/Execute switch to get to:

SAVE SETTINGS? Y N

Selecting **Y** will save the new settings. Selecting **N** will revert to the previous settings. Pushing the Menu/Execute switch then takes you to:

2.6.3 Alarm Indications

An alarm condition will occur if the local oscillator phase lock loop (PLL) comes out of lock. The Mute LED will light if you select to mute the Tx Signal and the Remote LED will light when you select the Remote mode.




FIGURE 2.5 Menu Display and Sequence

3.0 Environmental Use Information

- A. **Rack-Mounting** - To mount this equipment in a rack, please refer to the installation instructions located in the user manual furnished by the manufacturer of your equipment rack.
- B. **Mechanical Loading** - Mounting of equipment in a rack should be such that a hazardous condition does not exist due to uneven weight distribution.
- C. **Elevated Operating Ambient Temperature** - If installed in a closed or multiunit rack assembly, the operating ambient temperature of the rack may be greater than room ambient temperature. Therefore, consideration should be given to Tmra.
- D. **Reduced Air Flow** - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. Additional space between units may be required.
- E. **Circuit Overloading** - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of circuits could have on over current protection and supply wiring. Appropriate consideration of equipment name plate rating should be used when addressing this concern.
- F. **Reliable Earthing** - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connection to the Branch (use of power strips).
- G. **Top Cover** - There are no serviceable parts inside the product so, the Top Cover should not be removed. If the Top Cover is removed the ground strap and associated screw **MUST BE REINSTALLED** prior to Top Cover screw replacement. **FAILURE TO DO** this may cause **INGRESS** and/or **EGRESS** emission problems.



6170 Shiloh Road
Alpharetta, Georgia 30005

(770) 886-8005
FAX (770) 886-7964
Toll Free 888-900-5588

WEB: www.crosstechnologies.com
E-MAIL: info@crosstechnologies.com

Printed in USA