Instruction Manual

Model 1200-03 IF Processor

January 2009 Rev B



NONT	

Data, drawings, and other material contained herein are proprietary to Cross Technologies, Inc., but may be reproduced or duplicated without the prior permission of Cross Technologies, Inc. for purposes of operating the equipment.

When ordering parts from Cross Technologies, Inc., be sure to include the equipment model number, equipment serial number, and a description of the part.



6170 Shiloh Road Alpharetta, Georgia 30005

(770) 886-8005 FAX (770) 886-7964 Toll Free 888-900-5588

WEB www.crosstechnologies.com E-MAIL info@crosstechnologies.com

INSTRUCTION MANUAL

MODEL 1200-03 IF PROCESSOR

TABLE OF CONTENTS	PAGE	
Warranty	2	
1.0 General	3	
1.1 Equipment Description	3	
1.2 Technical Characteristics	4	
1.3 Use Information	6	
2.0 Installation	7	
2.1 Mechanical	7	
2.2 Rear I/O's, Control	8	
2.3 Front Panel I/O's, Indicators	8	
2.4 Operation	9	

WARRANTY - The following warranty applies to all Cross Technologies, Inc. products.

All Cross Technologies, Inc. products are warranted against defective materials and workmanship for a period of one year after shipment to customer. Cross Technologies, Inc.'s obligation under this warranty is limited to repairing or, at Cross Technologies, Inc.'s option, replacing parts, subassemblies, or entire assemblies. Cross Technologies, Inc. shall not be liable for any special, indirect, or consequential damages. This warranty does not cover parts or equipment which have been subject to misuse, negligence, or accident by the customer during use. All shipping costs for warranty repairs will be prepaid by the customer. There are not other warranties, express or implied, except as stated herein.



6170 Shiloh Road Alpharetta, Georgia 30005

(770) 886-8005 FAX (770) 886-7964 Toll Free 888-900-5588

WEB www.crosstechnologies.com E-MAIL info@crosstechnologies.com

MODEL 1200-03 IF PROCESSOR

1.0 General

1.1 Equipment Description - The 1200-03 IF Processor consists of a transmit and receive side. The receive side consists of one receive IF signal going through an Automatic Gain Control (AGC) amplifier and then split into three signals, DIG1RX, FDMRX, DIG2RX each having variable attenuators to adjust their levels over a 30dB output range via front panel multi-turn potentiometers. The AGC amplifier provides Automatic Gain Control for a 50 to 90 MHz IF signal for a -80 to 0 dBm input level to a -35dBm ±10dB output. A front panel monitor port provides a monitor signal out of the AGC amplifier.

The transmit side consists of three transmit IF signals combined into one. Transmit DIGTX, FDMTX, and DIG2TX signals each pass through individual attenuators controlled via front panel multi-turn potentiometers and a switch that is controlled remotely through a DB9 connector or locally with three 2PDT switches located on the front panel.

A 2PDT switch on the front panel selects either REMOTE or LOCAL operation. On the DB9 connector a closure to +V will turn the corresponding transmit channels on. A local override feature is included such that when the REMOTE/LOCAL 2PDT switch on the front panel is left in the LOCAL position, the override pin on the DB9 can be set to +V to override the LOCAL control and allow for REMOTE control. DIG1 and DIG2 on both transmit and receive sides are 75 Ω in/out while FDM on both transmit and receive sides are 50 Ω in/out. When power is removed from the 1200-03, the FDM TX and FDM RX signals pass through to the output.

The IF in and out connectors are BNC female. All circuitry is on a single PCB housed in a 1RU X 14" deep chassis. An internal switching power supply powers the unit with a 100-240 \pm 10% VAC, 47-63 Hz input.



FIGURE 1.1 Model 1200-03 Front and Rear Panels

1.2 Technical Characteristics

TABLE 1.1 1200-03 IF Processor Specifications*

RX In	put Characteristics	
	Impedance/Return Loss	50 Ω /18 dB
	Frequency	50 to 90 MHz
	Input Level Range/1dB	0 to -80 dBm / +5 dBm
RX O	utput Characteristics	
	Impedance/Return Loss	FDM RX 50 Ω / 18dB; DIG1, DIG2 RX 75 Ω /18 dB (with \geq 5dB
		attenuation on each channel)
	Output Level, nom/max	$-35 \pm 10 \text{ dBm} / -10 \text{ dBm}$
	Output Level Adjust	-35 to -65 dB \pm 10 dB at -35 dBm nominal
	RX IF Mon Output Level	$-35 \pm 10 \text{ dBm}$
RX Cl	hannel Characteristics	
	Gain, AGC	-35 to $+45$ dB range
	Frequency Response	±1.0 dB
TX In	put Characteristics	
	Impedance/Return Loss	FDM TX 50 Ω / 18dB; DIG1, DIG2 TX 75 Ω /18 dB (with \geq 5dB
		attenuation on each channel)
	Frequency	50 to 90 MHz
	Input Level Range	-20 to $+5$ dBm
	Input Level Adjust	0 to -30 dBm with 0 dBm in
TX O	utput Characteristics	
	Impedance/Return Loss	50 Ω /18 dB
	Output Level Range/1dB	-50 to +5 dBm / +10 dBm
TX Cl	nannel Characteristics	
	Gain Adjustment	0 to -30 dB, each channel individually adjustable
	Frequency Response	$\pm 1.0 \text{ dB}$
	Group Delay	5 ns, max
TX Sv	vitch Characteristics	
	Isolation, Switch off	$\geq 60 \text{ dB}$
	Isolation, Port to Port	\geq 50 dB, all "ON" and \geq 5dB attenuation on each channel
	Switch Time	$\leq 10 \text{ ms}$
Contr	ols, Indicators	
	Front Panel Controls	
	SW1, SW2, SW3	DIG1 TX, FDM TX, DIG2 TX switches (2PDT)
	SW4	LOCAL/REMOTE switch (2PDT)
	Front Panel Indicators	
	DIG1, FDM, DIG2	Green LED indicates DIG1 TX, FDM TX, DIG2 TX are "ON"
	OVERRIDE	Yellow LED indicates override of LOCAL control
	LOCAL	Red LED indicates SW4 set to LOCAL control
	DC	Green LED indicates power is supplied to the unit
	Front Panel Monitors	
	J1, J2	RX AGC Monitor, TX IF Out Monitor
Other		
	IF Connectors	BNC, female
	Connector, Control	DB9, female
	Size	19 inch standard chassis 1.75" high X 14.0" deep
	Power	$100-240 \pm 10\%$ VAC, 47 - 63 Hz, 30 watts max.

*+10 to +40 degrees C; Specifications subject to change without notice



1.3 Use Information

- **A**. **Elevated operating ambient temperature** if installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack may be greater than room ambient temperature. Therefore, consideration should be given to Tmra.
- **B.** Reduced air flow Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. Additional space between unit may be required.
- **C.** Mechanical loading Mounting of equipment in a rack should be such that a hazardous condition does not exist due to uneven weight distribution.
- **D. Circuit Overloading** Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of circuits could have on over current protection and supply wiring. Appropriate consideration of equipment name plate rating should be used, when addressing this concern.
- **E. Reliable Earthing** Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connection to the Branch (use of power strips).
- **F. Top Cover** There are no servicable parts inside the product so, the Top Cover should not be removed. If the Top Cover is removed the ground strap and associated screw MUST BE RE-INSTALLED prior to Top Cover screw replacement. FAILURE TO DO this may cause INGRESS and/or EGRESS emission problems.

2.0 Installation

2.1 Mechanical - The 1200-03 consists of one PCB assembly and one power supply housed in a 1 RU (1 3/4 inch high) by 14 inch deep chassis. An AC power supply provides +15VDC and -15VDC to the PCB. The 1200-03 can be secured to a rack using the 4 holes on the front panel. Figure 2.1 shows how the 1200-03 is assembled.



FIGURE 2.1 1200-03 Mechanical Assembly

2.2 Rear Panel Input/Output Signals and Controls - Figure 2.2 and Table 2.1 show the input, output. and control connectors on the rear panel.



FIGURE 2.2 1200-03 Rear Panel I/Os and Control



TABLE 2.1	- J105 (DB9) Contr	ol/Indicator Signals	
PIN	<u>CONTROLS</u>		
1	SELECT DIG1 TX IN	External Closure In	GND/Open OFF; +15 VDC(+V) ON
2	SELECT FDM TX IN	External Closure In	GND/Open OFF; +15 VDC(+V) ON
3	SELECT DIG2 TX IN	External Closure In	GND/Open OFF; +15 VDC(+V) ON
4	LOCAL Indicator OUT	Indicator Output	GND LOCAL Control; Open REMOTE Control
59	GND	Ground Reference	
6	OVERRIDE IN	Local Override Input	+15 VDC (+V) overrides LOCAL control and allows for REMOTE control
7	AGC OUT	AGC Voltage	Indicates current AGC gain (see Table 2.2)
8	+V	DC Voltage Reference	+15 VDC

2.3 Front Panel Controls and Indicators - The following are the front panel outputs, controls and indicators.



FIGURE 2.3 1200-03 Front Panel Controls and Indicators

2.4 Operation

2.4.1 Installing and Operating the 1200-03

- 1.) Install the 1200-03 in the equipment rack.
- 2.) Connect to signals on the CONTROL connector, J105, as desired (Figure 2.2).
- 3.) Connect 100-240 \pm 10% VAC, 47 63 Hz to AC IN on the back panel (Figure 2.2).
- 4.) Be sure the DC (power) LED, DS6, is on (Figure 2.3).
- 5.) Set SW4 for REMOTE or LOCAL operation (Figure 2.3).

6.) Choose the desired TX path(s) either remotely (J105, Figure 2.2) or locally using the front-panel switches (SW1 - SW3, Figure 2.3) and check for proper signal(s) at TX IF MON (J2, Figure 2.3) or TX IF OUT (J104, Figure 2.2) and that the appropriate LED(c) (DS1, DS2, Figure 2.2) is lit

TX IF OUT (J104, Figure 2.2) and that the appropriate LED(s) (DS1 - DS3, Figure 2.3) is lit.

7.) Adjust attenuator pots (R1, R2, R3, T1, T2, T3) as needed. Clockwise rotation provides

increased output level (full clockwise = 0 dB atten, full counter-clockwise = 30 dB atten).

8.) **AC Fuse -** The fuse is a 5 mm X 20 mm, 2 amp slow blow (Type T) and is inserted in the far slot in the drawer below the AC input as shown in Figure 2.4. There is a spare fuse in the near slot. If a fuse continues to open, the power supply is most likely defective.



FIGURE 2.4 Fuse Location and Spare Fuse

2.4.2 AGC voltage relating to Gain - The 1200-03 IF Processor operates over a 0 to -80 dBm input range on the RX IF side. The Automatic Gain Control (AGC) provides a constant -35 dBm \pm 10 dBm output RX IF level over the entire input range. Pin 7 of the DB9 control connector, J105, can be monitored to determine the approximate input level (and corresponding gain) in AGC as Table 2.2 shows.

TABLE 2.2 - Approximate AGC Voltage vs Gain and Input Level					
AGC Voltage (pin 7, J105)	<u>AGC Gain</u>	Input Level			
+0.3 VDC	-35 dB	0 dBm			
+0.1 VDC	-25 dB	-10 dBm			
-0.7 VDC	-15 dB	-20 dBm			
-1.4 VDC	-5 dB	-30 dBm			
-1.8 VDC	+5 dB	-40 dBm			
-2.1 VDC	+15 dB	-50 dBm			
-2.3 VDC	+25 dB	-60 dBm			
-2.5 VDC	+35 dB	-70 dBm			
-2.7 VDC	+45 dB	-80 dBm			



6170 Shiloh Road Alpharetta, Georgia 30005

(770) 886-8005 FAX (770) 886-7964 Toll Free 888-900-5588

WEB www.crosstechnologies.com E-MAIL info@crosstechnologies.com